

**Specifications:**

BT Version	5.3
Max Output	12W RMS
Battery Capacity	1200 mAh
Playback	1-2 hours*
Handsfree Calling	Yes
Dimensions	145 x 102 x 170mm

**Inside the box:**


- 1 x Bluetooth Speaker
- 1 x User Manual
- 1 x Charging Cable
- 1 x Warranty Card



Website: [www.artis.in](http://www.artis.in)  
 Customer care: 1800 123 8195  
 Email: [inquiry@artis.in](mailto:inquiry@artis.in)



Scan this QR Code to explore Artis products



- 12W RMS
- RGB LED Lights
- TWS Dual Spk. Pairing

**SoundMax 500**  
Wireless BT Speaker


**USER MANUAL**

**SoundMax 500** Wireless BT Speaker

Please read this user manual carefully before operating the speaker

**Functions**

**Wireless Mode:** When you turn on the speaker, you will first be in Wireless Mode. To connect, on your mobile device search for "Artis SoundMax 500"; and select to connect. In the future, the speaker will automatically connect to the last mobile device it was connected to if it is within range.



- 1.Power Switch:** Long press "Switch" button, Switch On/Off your speaker.
- 2.USB Input:** Play music directly from a USB device,Support up to 32GB.
- 3.Micro SD (TF):** Play music directly from your Micro SD card inserted. Micro SD playback begins automatically when Micro SD card is inserted. (When inserting Micro SD Card, keeps pin side on top) Support up to 32GB.
- 4.DC 5V Input:** Use the charging cable to charge your speaker. Connect to a USB adaptor or your laptop.
- 5.MODE Change Key:** Short press the "M" key to change the mode Wireless-FM/Bluetooth/USB/TF Card.(Long press the "▶||" button for 2-3 second to enter the automatic channel search mode. Use FM channel search, you need to plug in the USB charging cable on the speaker.)

- 6.Vol-/Previous Song:** Short press "-" to play previous song, Long press "-" for volume down.
- 7.Vol+/Next Song:** Short press "+" to play next song, long press "+" for volume up.
- 8.Play/Pause:** Short press "▶||" to play/stop playing music.
- 9.TWS Function:** Long press the "▶||" button under Bluetooth mode, you can hear "DID!" sound, it means 2 speakers are connected successfully. They will Auto Link when turn on speaker next time.
- 10.Hands-free device:** Click the "▶||" button to answer/hang up the call under Bluetooth Mode. Long press the "▶||" button to reject the call. Double-click the "▶||" button to redial the latest number.
- 11.Led Light:** Switch On your speaker, led light will turn on. Long press "M" button can change led light mode and switch off the led light.

**Troubleshooting**

- Some terminal music players are without automatic switching play function. In this case, a 'pop' noise may be heard between songs.
- If you cannot wireless connect to your mobile device. Try removing the Speaker from your mobile device's saved devices and re-connect as instructed above.
- The sound performance may also be affected when there is a weak connection between the mobile device and the speaker. To improve connection, bring the mobile device closer to the speaker or remove any obstacles between the two devices.
- The sound performance may also be affected if the battery power level is low on the Speaker. Please make sure the speaker is fully charged to improve this issue.

**Note:**

- Charge the speaker fully before first use.
- The charging time depends on the existing charged levels of the battery and the specifications of the USB adaptor.
- The LED indicator turns off automatically (during charging) when the battery is fully charged.
- The speaker's usage time depends on charge in the battery, mode, volume level, etc.